



## **Operating instructions microwave**

This microwave oven uses modern electronic control to adjust the cooking parameters to best suit your cooking needs.

### **1. Setting the clock**



When the microwave oven is switched on, the display shows "0:00", the buzzer sounds once.

- 1) Press "Reloj/Temporizador", the hour digit will flash;
- 2) Turn " " to adjust the hour digits, the input time must be between 0 and 23.
- 3) Press "Reloj/Temporizador", the minute digits will flash.
- 4) Turn " " to set the minute digits, the time entered must be between 0 and 59.
- 5) Press "Reloj/Temporizador" to finish setting the clock. The ":" display will flash.

Note: 1) If the clock is not set, it will not work when powered.

2) During clock setting, if no operation is performed for one minute, the oven automatically returns to the previous state.

### **2. Microwave cooking**

- 1) Press the "Micro/Grill/Combi." and "P100" is displayed.
- 2) Press the "Micro/Grill/Combi." button repeatedly or turn " " to select the power. "P100", "P80", "P50", "P30", "P10" are displayed in sequence.
- 3) Press "INICIW+30SEGICCONFIRM." to confirm.
- 4) Turn " " to set the cooking time (The time setting should be between 0:05 and 95:00).
- 5) Press "INIC10/+30SEGICCONFIRM." to start the cooking process.

NOTE: The intervals for the setting time of the coding switch are as follows:


- 0---1 min: 5 seconds
- 1---5 min: 10 seconds
- 5---10 min: 30 seconds
- 10---30 min: 1 minute
- 30---95 min: 5 minutes

## Functions and power



Micro/Grill/Combi order	Intervals	Power Oven	Grill power
1	P100	100%	
2	P80	80%	
3	P50	50%	
4	P30	30%	
5	P10	10%	
6	G	0%	100%
7	C-1	55%	45%
8	C-2	36%	64%

### 3. Grill or Combi. Cooking

Press "Micro/Grill/Combi" once. "The display shows "P100".

Press the "Micro/Grill/Combi. Press "Micro/Grill/Combi" repeatedly or turn "J" to select the desired grill power or combination and "G", "C-1" or "C-2" will be displayed. "Press "G", "C-1" or "C-2" for each additional press. Then press "INIC10/+30SEG/CONFIRM. to confirm, and turn "  " to set the cooking time from 0:05 to 95:00. Press "INIC10/+30SEG/CONFIRM. again to start cooking.


Example: If you want to use 55% of the microwave power and 45% of the grill power (C-1) to cook for 10 minutes, you can operate the oven as follows.

- 1) Press "Micro/Grill/Combi" once. "The display shows "P100".
- 2) Press "Micro/Grill/Combi" repeatedly or turn "  " to select the combi mode. 1.
- 3) Press "INIC10/+30SEG./CONFIRM." to confirm, and the display shows "C-1".
- 4) Turn "  " to set the cooking time until the oven displays "10:00".


Press "INIC10/+30SEG./CONFIRM" to start cooking.

Note: If half of the cooking time has elapsed, the oven will make two sounds, which is normal. In order to achieve a better toasting effect of the food, you should turn the food over, close the door, and then press "INIC10/+30SEG./CONFIRM. To continue cooking, press "INIC10/+30SEG./CONFIRM". If no operation is performed, the oven will continue to operate.

### 4. Quick start

- 1) In the standby state, press the "INIC10/+30SEG/CONFIRM. " to cook at 100% power level for 30 seconds. Each press of the same key can increase by 30 seconds. The maximum cooking time is 95 minutes.
- 2) During microwave, grill and combination cooking and defrosting time, press the "INIC10/+30SEG./CONFIRM. "to increase the cooking time.
- 3) In the standby state, turn "  " to the left to select the cooking time directly. After selecting the time, press "INIC10/+30SEG./CONFIRM." to start cooking. The microwave power is 100%.

#### 5. Defrost by weight

- 1) Press "Peso/Tiempo descong" once, the display shows "udEF1".
- 2) Turn " "to select the weight of the food. The weight range is from 100 to 2000 g.
- 3) Press the "INIC10/+30SEG./CONFIRM. " to start defrosting.



#### 6. Defrosting per hour

- 1) Press "Peso/Tiempo decong" twice, the display shows "dEF2".
- 2) Turn ".C)" to select the cooking time.
- 3) Press the "INIC10/+30SEGICONFIRM. "to start defrosting.

#### 7. Kitchen timer

- 1) Press "RELOJ/TEMPORIZADOR" twice, the display shows 00:00.
- 2) Turn the "'2" button to select the correct timer (maximum time is 95 minutes).
- 3) Press "INIC10/+30SEG./CONFIRM." to confirm the setting.
- 4) When the cooking time is reached, the timer light goes off. The buzzer sounds 5 times.

#### 8. Automatic menu

- 1) In standby state, turn " " to the right to select the menu from "A-1" to "A-8";
- 2) Press "INIC10/4-30SEGICONFIRM. "to confirm the selected menu;
- 3) Turn " " to select the weight of the food;
- 4) Press "INIC10/+30SEGICONFIRM. "to start the cooking process;
- 5) When the cooking is finished, the buzzer sounds five times.

Automatic menu

<b>MENU</b>	<b>Weight</b>	<b>Screen</b>
A-1 PIZZA	200g	200
	400g	400
A-2 MEAT	250g	250
	350g	350
	450g	450
A-3 VEGETABLES	200g	200
	300g	300
	400g	400
A-4 PATES	50g + 450ml water	50
	100g + 800ml water	100
A-5 POTATOES	200g	200
	400g	400
	600g	600
A-6 FISH	250g	250
	350g	350